



smartwares®



ALARM
FUNCTION



TOUCH
SCREEN

USB

POWER
CORD

mood light alarm clock

EN	Mood light alarm clock	NL	Alarm wekker met sfeerverlichting
DE	Wecker mit Stimmungsbeleuchtung	FR	Réveil avec éclairage d'ambiance
PL	Budzik z nastrojowym oświetleniem	ES	Reloj despertador con luz de ambiente

INSTRUCTION FOR OPERATION

1. SWITCH

Insert powerplug **D**
Touch on/off **A**

2. LAMP WHITE AND COLOURED LIGHT

Touch 'mode' to switch between white light and coloured light **B**

Touch COLOR/BRIGHTNESS control **C**
When the lamp is light on, touch the MODE button **B** to enter the color automatically changing mode, then touch anywhere on COLOR/BRIGHTNESS area **C** and choose any color you like, you can choose between 4 different colors.

3. TIME SETTING INSTRUCTION

Press SET button **E** 2 seconds to enter time setting mode. Press UP/DOWN **F G** button to adjust the hour; Press SET button **E** to change the minutes; Press UP/DOWN button **F G** to adjust the minute.

Press DOWN **G** to switch between 12-hour and 24-hour mode. Press DOWN **G** for 3 seconds to shut off/turn on the time display.

4. ALARM CLOCK INSTRUCTION

Press 'UP' **F** to switch between time setting and alarm setting (a clock will appear on the display for alarm setting).

Press SET button **E** 2 seconds to enter time setting mode. Press UP/DOWN **F G** button to adjust the hour; Press SET button **E** to change the minutes; Press UP/DOWN **F G** button to adjust the minute.


Press SET button **E** to finish alarm clock setting. When alarm rings, it rings for 1 minute.

Press ON/OFF button **A** to shut off the alarm.


ATTENTION

1. To avoid an accident, never put this product in fire or water.
2. Don't press two or more keys at the same time
3. If there is any malfunction caused, please connect the unit power again after unplugging for 3 seconds. If time display is malfunctioning, please press RESET **H** to reset.

Front



Back



GUARANTEE



2 YEARS

smartwares

safety & lighting

Broekakkerweg 15
5126 BD Gilze
The Netherlands

WWW.SMARTWARES.EU

NL : 0900-2088888 lokaal tarief

BE : 070-233031 lokaal tarief

FR : 0825 560 650 15ct/min.

DE : +49 (0) 1805 010762

14Ct./Min. dt. Festnetz,
Mobil max. 42Ct./Min

UK : +44 (0) 345 230 1231

ES : +34 938427589

CUSTOMER SERVICE

EN Intended for decorative purpose

NL Bestemd voor decoratieve doeleinden

PL Przewidziane do dekoracji

FR Prévu pour un usage décoratif

ES Para uso decorativo

DE Für dekorative Zwecke vorgesehen



Clock:
5VDC,
1.0A



Power adaptor:
Input: 100-240V
~50/60Hz, 0.3A
Output: 5VDC, 1.0A

