




# Wireless Pan/Tilt APP Camera

## Installation and Operating Instructions

**Model: CIP-39940**



PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT  
AND KEEP THIS MANUAL FOR FUTURE REFERENCE.

# CONTENTS

<b>Overview</b> .....	<b>2</b>
Please Read Before You Start .....	3
Wireless Device Operating Range .....	3
Important Safety Precautions .....	3
<b>Getting Started</b> .....	<b>5</b>
Kit Content.....	5
Safety and Installation Tips .....	6
Product Overview .....	7
LED Indicator.....	8
Install Your Camera .....	9
Setting up Your camera.....	10
<b>APP Introduction</b> .....	<b>12</b>
Main Page .....	12
Live View / Snapshot / Recording .....	14
View Your Snapshots .....	17
Playback Your Videos .....	17
Advanced Setting.....	23
<b>Trouble Shooting</b> .....	<b>30</b>
<b>Product Specification</b> .....	<b>32</b>
<b>Storage Media Management</b> .....	<b>33</b>

# OVERVIEW

---

The CIP-39940 camera is capable of delivering high quality Digital High Definition (HD) video to your smart-mobile device(s), which would require higher internet bandwidth. Due to your local internet environment condition, your mobile device(s) may display black-screen or temporary disconnect to the CIP-39940 camera.

- \* Make sure the CIP-39940 camera is operating with sufficient internet bandwidth, **1Mbps (upload/download speed) is suggested.**
- \* For the best performance, **the smart-mobile device(s) need to be on Wi-Fi or 4G mobile network** in order to receive maximum download speed.
- \* **When the internet transmission is low**, the APP will automatically switch to Relay Mode:
  - **By adjusting to “Better Streaming” in the system setting section the APP performance may improve.**
- \* **Your internet bandwidth is limited.** For best performance, avoid more than two users connecting to the CIP-39940 camera simultaneously.
- \* Make sure your smart-mobile device(s) is equipped with up-to-date technology, **1.5GHz dual core processor or equivalent is suggested.**
- \* **If the signal strength of your Wi-Fi router is weak**, there are several ways to improve range:
  - Change router/camera relative position to receive better signal.
  - Use wired Ethernet cable on the CIP-39940 camera to establish connection between CIP-39940 camera and your router.
  - Use Wi-Fi repeater/extender to maximize the service range of your Wi-Fi route.
  - Switch your router to 11b/11g mode in order to improve router service range.
  - Purchase extension cable or high gain antenna for your camera from the CIP-39940 vendor.
- \* Please make sure the memory card used is **CLASS10** rated.

## PLEASE READ BEFORE YOU START

Always use discretion when installing CCTV equipment, especially when there is perceived policy. Enquire relevant local regulations applicable to the lawful installation of video recording/surveillance. Third party consent may be required.

## WIRELESS DEVICES OPERATING RANGE

Ensure the signal reception viewed from the wireless camera(s) is the best possible reception between the camera(s) and the Wi-Fi router. If necessary, reduce the distance between the camera(s) and the Wi-Fi router to improve overall system performance. Wireless Color Camera Recordable CCTV Kit operating on a secure digital 2.4GHz frequency which could greatly reduce interference from product such as wireless routers, cordless phones or microwave ovens.

## IMPORTANT SAFETY PRECAUTIONS

Damages caused by non-compliance with this operating manual will void the warranty! We will not assume any liability for damages to items or persons caused by improper handling or non-compliance with the safety notices! Any warranty claim will be null and void in such cases.


1. Do not drop, puncture or disassemble the camera; otherwise the warranty will be voided.
2. Avoid all contact with water, ensure dry hands before using.
3. Never tug on the power cords. Use the plug to unplug it from the wall outlet.
4. Do not expose the camera to high temperature or leave it in direct sunlight. Doing so may damage the camera or cause camera temporary malfunction.
5. Use the devices with care. Avoid pressing hard on the camera body.
6. For your own safety, avoid using the camera or power off the camera when there is a storm or lightning.
7. Remove the power adapter during long periods between usages.
8. Use only the accessories and power adapters supplied by the manufacturer.
9. To meet the regulations pertaining to parental responsibility, keep the devices out of the reach of infants.
10. Check power cables do not get crushed or damaged by sharp edges whenever the devices are in operation.




# KIT CONTENT

---


Wireless App Camera




RJ45 Connect Jack



Camera Antenna




Power Adapter



Hex Key



Quick Start Guide



Screw Pack



**Tools Required:**

- Electric drill
- 5mm masonry drill bit
- 15mm masonry drill bit
- No. 2 Philips screwdriver

**For best system performance:**

- iOS: iPhone5 / iPad2 / Mini iPad with iOS 7.0 or above.
- Android: 1.5G dual core processor dual core processor with 1G Ram or above.
- Storage: Class 10 memory card.
- Bandwidth: 1Mbps or above upload/download speed suggested.

# SAFETY AND INSTALLATION TIPS

---

Do not attempt to open the units with the power adaptor plug connected to avoid any risk of personal injury.


When installing CCTV camera(s), always follow manufacturer's advice when using power tools, steps, ladders, etc. and wear suitable protective equipment (e.g. safety goggles) when drilling holes. Before drilling holes through walls, check for hidden electricity cables and water pipes. The use of cable/pipe detector is advisable.

To avoid exposing any cameras to extreme weather conditions (e.g., under a gutter which is prone to any water leaks). When installing any cameras with this unit, to use cable conduit to protect any video/power extension cables from being exposed externally and to prevent/reduce the chances of the cables being tampered with. After drilling any hole through an external wall for a cable, ensure the hole is sealed up around the cable using a sealant to prevent drafts.

To prevent a fire or electrical shock hazard, do not attempt to open the housing while the unit is exposed to rain, water or wet conditions. There are no user serviceable parts inside. Refer servicing to qualified service personnel. Avoid pointing the camera(s) directly at the sun or any bushes, tree branches or moving objects that might unnecessarily cause the camera to record.

# PRODUCT OVERVIEW


## Camera



**Note:**

Press and hold the “Reset” button for 5 seconds. All settings are restored to the factory default.

## Interface Connection



# LED INDICATOR

---

STATUS	DESCRIPTION
Power On	Power on the camera and wait until the RED LED indicator becomes steady on. This process would be finished within 45 seconds and make sure the LED is flashing in RED.
Soft AP	RED LED flashes once followed by 2 short flashes.
Reset factory under Soft AP	RED LED flashes quickly
Default Reset	RED LED flashes quickly
Update Firmware	RED LED flashes quickly
Start Recording Video	RED LED flashes once







## Install Your Camera

1. Drill the mounting holes by using the alignment paper.
2. Insert the 4 screw anchors into the wall.
3. Insert the 4 screws into the screw anchors and reserved space 8 to 10 mm .
4. Hang the camera on the 4 screws, then fasten 4 screws by using hex key.

**Note:**

Before mounting the camera, install the memory card if you prefer recording video to local storage.



# Setting up Your Camera

Follow the instructions below to help configure your camera for initial use.

## 1. APP download

Download and install the "Smartwares view" APP to your device.



For iOS




For Android

## 2. Power on the camera


Connect the power wires to the adapter supplied, and wait until the RED LED indicator becomes steady on. This process would be finished within 1 min and make sure the LED stops flashing in RED.

## 3a. Wireless Connection

- (1) In the Wi-Fi setting of your smart device. Choose the Wi-Fi router with prefix of HD-xxxxxx (xxxxxx=Camera ID numbers). Then enter the default password 12345678.
- (2) Launch the APP, tap **+** to add the camera.
- (3) Tap (QR code icon) and scan the QR code label on the back of the camera to bring up the DID information. Or tap "Search" to locate the camera.
- (4) Enter the default password 123456.
- (5) Tap "Save" when you done.
- (6) Later, APP will request user to modify the default password to private password .




(iOS)




(Android)

### 3b.Wired Connection

1. Make sure your smartphone is connected your Wi-Fi router.
2. Connect the camera's Ethernet cable to the Rj45 connect. The other side, connect to the Wi-Fi router, and power on the camera with adapter.
3. Launch the APP, tap "Search" to locate the camera.
4. Enter the default password 123456 and save the settings.
5. Later, the APP will request user to modify default password to private password .



6. Open the advanced settings and enter the default admin password (123456). The APP will ask you to change the admin password now. In advanced settings, go to Wi-Fi settings. Choose the appropriate Wi-Fi router on your local network. The Camera will go offline for around 40 seconds to reboot for Wifi-connection. When camera connects to Wi-Fi router correctly, the RED LED will stay ON.




# APP INTRODUCTION


---

## Main Page

The MAIN PAGE section offers user an overview for all registered camera(s), including camera status (connected/disconnected). User can quickly access the camera(s) in the list. When multiple cameras are registered, scroll down to locate the registered camera for access.



(iOS)



(Android)




The ADD CAMERA icon allows you to register additional camera(s) to the system. The system supports up to 3 concurrent user connections.




In the CAMERA SETTING section you will allow to (1) configure system setting, (2) unregister camera from the APP and (3) enter event list for recorded video file(s) playback. Tap the CAMERA SETTING icon to enter/exit CAMERA SETTING.

Tap the CAMERA SETTING icon. The following icons appear on the panel.



(iOS)



(Android)



Tap the **ADVANCED SETTING** icon to setup camera configuration. (Please refer to "Advanced Setting" for detail).



Tap the **DELETE** icon to remove the camera connection.




Tap the **EVENT LIST** icon to check or playback the recorded events. (Please refer to "Playback Your Video" for detail).



The **INFORMATION** icon allows you to enable PIN lock, push notification function and check the App information.

# LIVE VIEW / SNAPSHOT / RECORDING

---



Tap to take snapshot image(s) of the video. The captured snapshots will be stored in your mobile device.



Tap to turn ON/OFF the volume.



Tap to Start/Stop recording. The recorded video file will be stored in the memory card of your camera.




Tap to set/move camera to default position




Tap to return to the main page.

## Record the point

This function allows you to save a camera position. You're able to select the saved point so the camera turns to this position. Follow the below instruction to set up.

1. Rotate the camera in live video mode to the point you want to record.
2. Tap  to enter the record the point.
3. Select the point you want to save.



The APP allows users to have access to live video. Users can take snapshot image(s) and record the live video.

If you're using the indoor model, you can also choose the color tone according to the lighting condition. By default, the APP applies the 'indoor' option with a warm-yellow color tone for the indoor models. You can also choose the 'outdoor' option in the advanced setting for cool-white color tone if it best fits your viewing environment. It is not necessary to change this setting for outdoor models.



When you launch the App on the smart phone or tablet, the image displaying on the main screen is the very last automatically captured snapshot from the live view of the previous established session. Tap the image to enter the live view mode.

The controls and layout of the APP have been customized to meet the operating system requirements of the mobile device. The main page may vary, depending on your mobile device. By default, the live view is displayed in portrait mode. You can also turn the device sideways to switch to landscape mode for a larger view.

**Note:**

Once the recording is started by motion detection or manually, the APP will continue the recording for 1 minute. User cannot stop the recording during this period.



# VIEWING YOUR SNAPSHOTS

---

## For iOS

Your snapshots will be named with the time stamp and saved into the Camera Roll location of your mobile device.

## For Android

Your snapshots will be named with the time stamp and saved into the **Photo Gallery > snapshot** folder on your mobile device.


# PLAYBACK YOUR VIDEOS

---


The recorded video file(s) on your camera is automatically saved to the memory card inserted in your camera. You can remotely access the file(s) for playback via your mobile device.



Tap the CAMERA SETTING icon on the main page.





(iOS)




(Android)



Tap EVENT LIST icon and the Date-Time filter will appear. User may define the period for system to display all available recorded file(s) for playback.



During the playback, you can tap the PAUSE icon to pause / resume the video, MUTE to deactivate/activate the audio function and GO BACK icon to return to the event list section. You may also review recorded video file(s) with your PC. For best performance, please use "Free Video Converter" from [http://www.freemake.com/free\\_video\\_converter/](http://www.freemake.com/free_video_converter/), or Video LAN from <http://www.videolan.org/>. The video is using FFmpeg codes and is H.264 compression method.



1. Tap to pause/play video
2. Tap to view full screen


User's local network environment condition (example: upload/download speed) may cause improper video playback (black screen), when it happens, please leave the playback mode and try again at later time.

APP layout may vary depending on the display panel size of your mobile devices. Please refer to the release note from the APP Store/Google Play for more details.

This function helps user to easily transfer the recorded file(s) from the memory card. It is strongly suggested to download the file(s) at your home Wi-Fi network (WLAN), meaning the mobile device(s) is connecting to the same Wi-Fi router as the camera. Minimum bandwidth requirement is 1Mbps (upload/download). Download process may be force stopped if the bandwidth becomes too slow and cannot continue.


**Note:**  
For iOS system, please use "Oplayer Lite" APP for playback downloaded video files(s). You can find "Oplayer Lite" from App Store (free of charge)

**Note:**  
For Android system, please use "MX Player" APP for playback downloaded video file(s). You can find "MX Player" from Google Play (free of charge).  
If you are experiencing scattering video image, please switch the decoder function of the MX Player to "S/W Decoder".




**Delete**

First select the file(s) by tapping the file name, following by taping on the Trashcan icon to delete selected file(s) Multiple files can be selected for delete.



To Download / Delete the video file(s) in the EVENT LIST section, please follow the steps below:



### Download


Long press the video clip to download the file onto your mobile device.



### Note:

During the download process, system will stop both the live view and recording functions. APP will automatically inform any user accessing the camera that the system is busy and the connection has been terminated.

## Setup PIN Lock



If you enable PIN Lock, the user will be asked to enter the PIN code when you launch the APP.

1. Enable the “Enable lock when starting” function. Then enter your PIN code.
2. Confirm your PIN code again.

### Note:

If you forgot your PIN code, please uninstall the APP and reinstall it on the mobile device.

## Notify (Push Notification)

The CIP-39940 camera supports motion detection function. When any event is detected in the camera site, you'll receive push notification on the mobile devices for the event recognized by the camera.

### For iOS


1. If you want to enable/disable it, follow the steps on your iOS mobile device:
2. Tap Notifications.

### Note:

It takes time for the changes to take effect in iOS, normally within 2 hours.

### For Android

If you want to enable/disable it, please follow the steps below.



**Note:**

The internet connection and wireless network interference may influence the performance of push notification service.

### About app/API Version Info

Tap the ABOUT icon to check the APP Version when necessary.



**Note:**

The internet connection and wireless network interference may influence the performance of push notification service.

# ADVANCED SETTING

---

This chapter explains the advanced settings for administrator. Administrator is the one who owns the administration password and has the full control to the CIP-39940 camera. The administrator can access all CIP-39940 functions and settings, while general users can receive the surveillance images for live view/screen capture/video recording and may not manage the camera settings.

Admin Password	The security code required to enter Advanced Setting for system setting management
IP Cam Name	Give your camera a name
Time Zone	Set up the appropriate time zone
Device Security Code	The password required for remote access
Video Setting	Configure the video quality and local power frequency
Wi-Fi Setting	Manage your Wi-Fi Network
Sensitivity Setting	Set up the camera sensitivity for motion detection
Motion Mask	Use quick de-select and/or tap screen.
TimeStamp	Select a color for the tab of time
Email Setting	Set up your email account for E-mail alert
SD Card Setting	Format the SD card
Device Information	Check the App and API Kernel version

**Note:**

It may take more than one minute for some routers to update the registered devices. When you complete advanced settings and return to device list, please wait for a while allowing your router to finish the camera registration.

## Admin Password

The Admin Password is a specific security code for administrator to change the advanced settings. The default admin password is 123456.

Please use this function to change the default admin password into your personal admin password. For the protection of your system configuration, every time you change the advanced settings, you need to enter the admin password. Please change the admin password periodically.

### Note:

If you forget your admin password, press and hold the reset button for 5 seconds, all settings will restore to factory default. You will need to configure your camera from the start.

## IP Cam Name

Name and change your camera's name.

## Time Zone

The drop-down list shows the world time zone. Select the time zone that will work best for you. If your date/time is during the daylight saving time period, please check the Daylight Saving box to adjust the system time properly.

## Device Security Code

The Device Security Code is a specific security code to access the camera.

The default password of the camera is 123456. Use this function to change the default password into your personal security code.

1. Type in the old password.
2. Type in the new password and confirm the new password again.
3. Tap OK to save the setting.

### Note:

1. Change password in system information page accordingly.
2. If you forget the Device Security Code, press and hold the reset button for 5 seconds to reset the system to factory default. All settings will restore to factory default. You will need to configure your camera from the start.




## Video Settings

This section allows you to configure the video quality and environment mode.

### Video Quality

The Video Quality setting section allows you to adjust the quality of the video streaming. By selecting better video image will allow you to view high resolution image. By selecting 'better streaming' the video will be displayed more smoothly (quality depends on local internet environment).

Only select better image when you have sufficient bandwidth and updated mobile device(s). Please refer to P.4 for system requirement.



### Environment Mode

The Environment Mode settings allows you to select the power line frequency used at the location of CIP-39940 camera. The power line frequency varies depending on geographic region. It may cause image flicker if wrong frequency is selected. Please check with local authorities for proper setting.

There are two type video color tone, user can change the video color tone between warm-yellow(indoor) and cool-white (outdoor).

### Low Light Enhancement

The Low Light Enhancement Mode is for improving the night view video image by providing 5 levels to select from (5 = brightest).

## Wi-Fi Setting

The Wi-Fi setting allows you to choose the wireless connection and set up the Wi-Fi environment.

When you tap the “Manage Wi-Fi network” button, the system automatically scans the nearby network and shows the available Wi-Fi routers in the drop-down list. Choose the appropriate Wi-Fi router and enter the Wi-Fi router password if necessary. Due to security concerns, it is suggested to use the WPA/WPA2/ WPA2-PSK protocol for Wi-Fi network.

### Note:

1. When the Wi-Fi connection is completed and you unplug the Ethernet cable, the camera will reboot and it will take several minutes to establish the connection. Please re-launch the APP when you see the green signal indicator lights up.
2. The CIP-39940 camera is designed to work with the legal Wi-Fi channels in your region. Please refer to your Wi-Fi router manual to choose an appropriate channel for CIP-39940 camera.
3. If camera fails to connect to the Wi-Fi router, please hold down reset button for 2 seconds to reset the system and repeat register process again.

## Sensitivity Setting

This defines the camera parameter for motion detection.

### Detection Mode


PIR is hardware-based biomass detection.

SOFTWARE use advance software analysis to trigger motion alarm.

### Motion Detection (available for Software Mode ONLY)

HIGH – Suitable for detecting smaller object(s) within 5 to 6 meters

LOW – Suitable for detecting larger object(s) within 3 to 5 meters




### Note:

The HIGH/LOW setting for Motion Detection only takes effect when user chooses SOFTWARE in detection Mode.

## MOTION MASK


This function allows you to quickly select motion mask from 3 default model. In addition, the user is able to tap screen which area you don't want to be detected.



1. Tap the area where you don't want to detect the motion.
2. 3 icons for quick tapping of bar area.
3. Reset button.
4. Save setting.

## TIMESTAMP

This section allows you to change the time stamp background color. Drag and drop where you want to place the time stamp.



1. The time stamp locates at the corner where you tap.
2. Tap to change the time stamp background color.

## Email Setting

The email setting allows you to configure the email environment, email account and password. Gmail account is suggested.

Click the “Use SSL” check box will transmit the data in encryption. This setting requires the Simple Mail Transfer Protocol (SMTP) configuration. Most ISPs use the SMTP method to transfer outbound mail via the internet. Only use the SMTP that supports SSL.



Gmail Setting (suggested)		
SMTP Server	smtp.gmail.com	Enter the gmail SMTP server
SMTP Port	465	Enter the SMTP port 465
Username	XXX@gmail.com	Enter your email address
Password	XXXXXXXX	Enter the password for this gmail account
Email to	XXX@gmail.com	Enter the email address for the recipient who receives the email alert.

## SD Card Setting

Formatting your memory card will **ERASE** all the data from it and you will not be able to get the data back. Please back up your video files **BEFORE** formatting the memory card.

**Note:**

The system is optimized to Class 10 memory card. Memory card with lower specification will decrease the recording and playback function efficiency.

During format process, all recording & viewing will stop until format process completes.

## Overwrite SD Card

This function will overwrite the oldest files when the micro memory card is full. Turning on this function will enable the system to start overwriting the old files when the available memory card capacity is not enough. This ensures the most up to date video recordings can be saved so that you won't miss any important information.

**Note:**

You will want to reformat the memory card from time to time to ensure the condition of the storage device. Your camera system will not work properly if the memory card becomes corrupted.

## Device Information

This section shows the device information about the camera, including device version, total size and available size of the memory card.

# TROUBLE SHOOTING

IF	SOLUTION
The APP can not find the camera	<ul style="list-style-type: none"> <li>• Make sure your network supports the DHCP protocol.</li> <li>• Make sure the camera and your mobile device connect to the same Wi-Fi router for the first setting.</li> <li>• Make sure the Wi-Fi router is activated.</li> <li>• Make sure the camera is properly powered on.</li> <li>• Use the “ADD CAMERA” function to manually add the camera.</li> </ul>
Wi-Fi router is not shown in the drop down list	<ul style="list-style-type: none"> <li>• Make sure SSID broadcasting function is enabled in the Wi-Fi router. Consult your Wi-Fi router manufacturer for the settings if necessary.</li> <li>• Change the wireless security protocol of your Wi-Fi router into WPA/WPA2/WPA2-PSK. Due to security concerns, WEP protocol is not suggested for some Wi-Fi routers.</li> </ul> <div style="border: 1px solid #ccc; border-radius: 10px; padding: 10px; margin-top: 10px;"> <p><b>Note:</b> WPA/WPA2/WPA2-PSK encryption protocols are newer and more effective security standards for wireless networks than the older and less-secure WEP protocol.</p> </div>
No image appears	<ul style="list-style-type: none"> <li>• Make sure the power adaptor is not damaged or defective and plugged into an electrical outlet with power.</li> <li>• Relocate the camera to obtain the best reception of wireless signals.</li> <li>• Make sure the camera is properly configured in App.</li> <li>• Make sure the mobile device is connected to 3G/4G/Wi-Fi properly.</li> </ul>
Low wireless signal Poor image quality	<ul style="list-style-type: none"> <li>• Wireless devices such as wireless home stereo system may reduce the signal strength. Leave as much space as possible between the camera/mobile device and these wireless devices.</li> <li>• Clean the camera lens using lens cleaning cloth. Spots or dust on the lens can also cause image quality problems.</li> </ul>
Motion detection is not working or over-react	<ul style="list-style-type: none"> <li>• Make sure the sensitivity setting is turned ON (please refer to the Sensitivity Setting section).</li> <li>• In motion detection mode, a moving object within the camera viewing angle is necessary to trigger the motion sensor for recording</li> </ul>

<p>The APP can not record any video clips</p>	<ul style="list-style-type: none"> <li>• Make sure the SD card has been correctly inserted</li> <li>• Make sure the motion detection function has been enabled. (please refer to the Sensitivity Setting section).</li> <li>• Please format the SD card when it is used for the first time (please refer to the SD Card Format section)</li> <li>• Make sure you are using Class 10 rated memory card.</li> </ul>
<p>Email alert is not working</p>	<ul style="list-style-type: none"> <li>• Make sure the email alert function is enabled (please refer to the Email Alert section).</li> <li>• Gmail account is suggested for the email alert function. Make sure you have setup the system configuration as suggested in the Email Alert section.</li> <li>• Make sure the email address is entered correctly.</li> </ul>
<p>Bright white spots appear at night time</p>	<ul style="list-style-type: none"> <li>• The camera's infrared LEDs produce invisible light that reflects off surfaces such as glass. Install the camera on the other side of windows or place the lens flush against the surface to improve the night vision. It is suggested to install camera(s) under well-lit area.</li> </ul> <div style="background-color: #f0f0f0; padding: 10px; border-radius: 10px; margin-top: 10px;"> <p><b>Note:</b> Please check the environment rating (Ingress) of the camera(s) before installing outdoors.</p> </div>
<p>Memory card error</p>	<ul style="list-style-type: none"> <li>• Make sure the memory card is correctly inserted and formatted.</li> <li>• Use the provided memory card within the package to ensure proper operation.</li> <li>• Make sure your are using Class 10 rated memory card.</li> </ul> <div style="background-color: #f0f0f0; padding: 10px; border-radius: 10px; margin-top: 10px;"> <p><b>Note:</b> Please backup the data before formatting. Format function will erase all the data on the memory card.</p> </div>
<p>Wrong data and time are shown</p>	<ul style="list-style-type: none"> <li>• Wrong date and/or time will result in unexpected record schedule. Make sure you've selected the correct time zone (please refer to the Time Zone section).</li> <li>• Confirm the system date/time of the mobile device to ensure correct operation.</li> <li>• System will clock itself when connect to the internet. Make sure the system is connected properly to the internet. You may use your mobile device to access the system to see if remote view is functioning properly.</li> </ul>

# PRODUCTION SPECIFICATION

<b>Networking Parameter</b>	
Wireless Technology	IEEE 802.11 b/g/n
Network Connection	Ethernet (10/100 Base-T/Base -TX); Wi-Fi
Network Protocols	TCP/IP, UDP, SMTP, NTP, DHCP, ARP
Simultaneous Viewers	3 concurrent sessions
Security	WPA /WPA2/WPA2-PSK (TKIP, 128 bit AES)
<b>Camera Parameter</b>	
Image Sensor	2 MegaPixel, 1/2.7" CMOS
Antenna	3dBi Dipole
Environment Rating (Ingress)	IP66
Light Source Environment	Indoor (50Hz/60Hz)
Local Storage	Micro SD Card up to 128GB(not included in the package)
Pan/Tilt	Pan: 270° (9.74° each step ) Tilt: 90° (9.56° each step)
Viewing angle	H: 90°, V: 45°±3°
Lens	4.0mm±5%mm
Min. Illumination	1~8 lux
Number of LEDs	12 IR LEDs with IR switcher
IR Distance	8 to 10 meters
<b>Video Audio Parameter</b>	
Image Compression	H.264
Image Resolution	Full HD 1920x1080P
Recording Frame Rate	Up To 30 FPS
<b>Supported Mobile Device</b>	
iOS requirement	iPhone 5S/iPad air with iOS 9.0 or Above
Android requirement	Android 4.4X or above
Hardware requirement	1.5GHz dual core or above 1GB or above internal memory
<b>General Parameter</b>	
Power Requirements	100~240V switching power supply DC 5V 1.5A
Operating Temperature	-10°C~+50°C



# STORAGE MEDIA MANAGEMENT

---

<b>Micro SD Card Capacity (Class 10)</b>	<b>Full HD Video</b>
8G	340 Events
32G	1300 Events
64G	2700 Events
128G	5500 Events